

IBS CMD SWT G4 4.6 SP - Configuration and diagnostic software

2730789

<https://www.phoenixcontact.com/us/products/2730789>

Please be informed that the data shown in this PDF document is generated from our online catalog. Please find the complete data in the user documentation. Our general terms of use for downloads are valid.



Network configuration software for INTERBUS Generation 4

Product description

A bus system for open, flexible control architectures must provide the user with a concept for universal and, above all, manufacturer-independent operation and diagnostics of a system, in order to provide the required manufacturer-neutrality. The configuration, startup, and diagnostics software CMD (Configuration Monitoring Diagnostics) was developed for INTERBUS. The key features of this software are the independence from the control system used and the flexibility with regard to program expansions, new functions, and utility programs. The DRIVECOM user group, for example, offers utility programs for parameterizing drives according to the DRIVECOM profile.

In order to meet the requirements of users, we continue to apply our INTERBUS expertise to this software.

CMD for all phases:

CMD is a tool that can be used throughout the entire lifecycle of a plant, from planning and configuration, through system startup and operation monitoring, and beyond to diagnostics in the event of maintenance. For the user this eliminates the costs and effort of learning to use several software tools.

The CMD software allows the user to determine the configuration of the INTERBUS system during the configuration phase. The I/O points can be assigned logical addresses or variables, through which the control program will later access the distributed I/Os.

During startup, a function test can be carried out on subsystems using an integrated monitor function.

The diagnostic functions continuously provide detailed information about the bus status, possible error causes, and suggestions on how to remedy them.

CMD for globally established operating systems:

CMD can be run under Windows operating systems for standard PC systems (Windows® NT 4.0 SP6, Windows® 2000, Windows® XP). The familiar interface makes it easy to get started with the software and thereby operate the entire INTERBUS system easily and safely.

The CMD G4 software is not released for Windows 7 operating systems and above. However, the follow-up software Config+ also supports current and future operating systems.

Commercial data

| | |
|--------------------------------------|--------------------------------|
| Item number | 2730789 |
| Packing unit | 1 pc |
| Minimum order quantity | 1 pc |
| Note | Made to order (non-returnable) |
| Sales key | 11 |
| Product key | DRDBAY |
| GTIN | 4017918952341 |
| Weight per piece (including packing) | 452 g |
| Weight per piece (excluding packing) | 452 g |
| Country of origin | DE |

IBS CMD SWT G4 4.6 SP - Configuration and diagnostic software



2730789

<https://www.phoenixcontact.com/us/products/2730789>

Technical data

Notes

| | |
|--------------------|--|
| Order information: | CMD is also available in English, French, Spanish, Portuguese (Brazilian). |
|--------------------|--|

Product properties

| | |
|--------------|-------------------------------|
| Product type | Configuration and diagnostics |
|--------------|-------------------------------|

System properties

| | |
|-------------------------------|--------------------------|
| Intended use for the software | Configuration |
| | Diagnostics |
| | Data acquisition |
| | Communication |
| | Startup |
| | Maintenance |
| | DIN EN 61131-3 compliant |
| | Security |

License information

| | |
|-----------------|---------------------|
| Type of license | Single-user license |
|-----------------|---------------------|

Functionality

| | |
|----------------------|--|
| Basic functions | Executing important commands (start/stop/...) |
| | Reading in the installed bus structure |
| | Detecting/representing error states (plain text from knowledge database) |
| | Saving diagnostics data in flash memory or parameterizing memory of the controller board |
| | Diagnostics of INTERBUS FO paths (transmission quality) |
| | Configuration comparison of Ethernet topologies (parameterized with real topology) |
| | Reading out the Controller Diagnose Archive |
| Integrated function | Diagnostics |
| | Evaluation |
| | Data acquisition |
| | Startup |
| | Communication |
| | Configuration |
| | Maintenance |
| Associated hardware | 4th generation INTERBUS controller boards, PROFINET controller (Phoenix Contact only) |
| Supported controller | INTERBUS generation 4 controller boards, PROFINET controller (Phoenix Contact only) |
| Number of I/O nodes | not relevant |

IBS CMD SWT G4 4.6 SP - Configuration and diagnostic software



2730789

<https://www.phoenixcontact.com/us/products/2730789>

System requirements

| | |
|---------------------|---|
| Operating equipment | Keyboard, mouse |
| Operating system | Windows® NT 4.0 SP6 |
| | Windows® 2000 |
| | Windows® XP |
| Processor | Min. 80486/ 33 MHz |
| Hard disk memory | 62 Mbyte |
| Interfaces | Free serial interface for online connection |
| Languages supported | Spanish |
| Optical drive | CD-ROM |
| Screen resolution | SVGA mit min. 800 x 600 |

IBS CMD SWT G4 4.6 SP - Configuration and diagnostic software



2730789

<https://www.phoenixcontact.com/us/products/2730789>

Classifications

ECLASS

| | |
|-------------|----------|
| ECLASS-13.0 | 27242501 |
|-------------|----------|

ETIM

| | |
|----------|----------|
| ETIM 9.0 | EC000809 |
|----------|----------|

UNSPSC

| | |
|-------------|----------|
| UNSPSC 21.0 | 43233600 |
|-------------|----------|

IBS CMD SWT G4 4.6 SP - Configuration and diagnostic software



2730789

<https://www.phoenixcontact.com/us/products/2730789>

Environmental product compliance

EU RoHS

| | |
|---|---|
| Fulfills EU RoHS substance requirements | Not applicable, No electrical and electronic equipment (EEE), cannot be used in EEE |
|---|---|

EU REACH SVHC

| | |
|-------------------------------------|----------------------------|
| REACH candidate substance (CAS No.) | No substance above 0.1 wt% |
|-------------------------------------|----------------------------|

Phoenix Contact 2026 © - all rights reserved
<https://www.phoenixcontact.com>

Phoenix Contact USA
586 Fulling Mill Road
Middletown, PA 17057, United States
(+717) 944-1300
info@phoenixcon.com